

EP-600 SERIES DC REGULATED POWER SUPPLY

USER'S MANUAL


I. GENERAL

EP-600 Series DC Regulated Power Supply is a completely solid state, compact, well regulated, constant voltage power supply suitable for service field, hobby & general use. For safety purpose, a three-wire power cord is provided.

II. FEATURES

1. Overload and Short Circuit Protection: Prevent the unit from overload and short circuit. When the unit is under the condition of overload or short circuit, the output current will be limited.
2. Independent 5V, 12V Easy Snap-On fixed output terminals (EP-603 & EP-613 only) to make it easy to use for TTL and CMOS circuit test. The grounding of the output terminals is independent that the output can be connected in series to make a higher output voltage.

III. FRONT AND REAR PANELS



1. ON/OFF Switch
2. Power Indicator
3. Voltmeter
4. Ammeter
5. Current Limited Indicator
6. Easy Snap-On Output Terminals

7. Screw-On Output Terminal
8. Voltage Adjustment Knob
9. Current Adjustment Knob
10. Fuse Holder
11. Power Cord

IV. OPERATION

A. Installation:

1. Place the unit in a location where allows free air circulation.
2. **DO NOT** place the unit in high humid, dusty and/or sunny places.
3. The input power source must be $\pm 5\%$ of the rated input voltage.

B. Caution:

1. **DO NOT** use the unit for equipment that requires higher current ratings than the unit is designed for, otherwise damage could occur to the unit.
2. **DO NOT** replace the fuse before ceasing the problems and assigned value of fuse must be used in place.

C. Safety Precautions:

The following precautions **MUST** be read carefully to prevent from electric shock.

1. **NEVER** remove the metal cover of the power supply while power source is connecting.
2. **NEVER** touch the power supply when your hand is wet.
3. **NEVER** operate the power supply if foreign materials such as metallic objects, water or other debris have fallen inside. Contact your dealer for check and repair.
4. **NEVER** operate the unit that was being damaged. As the voltage regulation circuitry may have been disabled, the resulting high DC voltage could cause damage to your equipment.
5. **NEVER** allow foreign objects to touch the output terminals.
6. If you have the need to inspect the interior of the power supply, be contained to let it cool down completely, as some components may be hot enough to burn your hands in event of component failure (People other than professions are not recommend to check the interior yourselves.)

D. Connection and Operation:

1. Turn OFF the unit and the equipment.
2. Connect the equipment to the unit. Positive polarity to red (+) and negative polarity to Black (-).
3. Turn ON the unit first and then turn ON the equipment.
4. When an operation is finished, turn OFF the equipment first and then turn OFF the unit.

V. SPECIFICATIONS

MODEL NUMBER:	EP-601	EP-603	EP-611	EP-613
OUTPUT VOLTAGE:	0-30V DC			
OUTPUT CURRENT:	2.5A			
RIPPLE & NOISE:	5mV _{r.m.s.}			
LINE REGULATION:	0.05% + 10mV			
LOAD REGULATION:	0.05% + 10mV			
FIXED VOLTAGE 1:	Nil	5V/0.5A	Nil	5V/0.5A
FIXED VOLTAGE 2:	Nil	12V/0.5A	Nil	12V/0.5A
POWER SOURCE:	230Vac/50Hz (120Vac/60Hz or on request)			
METERS TYPE:	ANALOG METERS		LCD METERS	
DIMENSION (W×H×D):	150 × 145 × 200 (mm)			
WEIGHT:	2.8 Kg (Approx.)			
ACCESSORY:	Instruction Book			